

AdelWiggins W900 Series Flexible Connector Installation

After ferrules have been attached to tubes by swaging or welding,
installation is made as follows:

À

- Install "O" Ring seal on each ferrule (lubricate before installing).
- Install body on one ferrule.
- Pull body back over other ferrule.
- Install clamp assembly on body.
- Engage latch assembly.
- Close into locked position.

Note: Ferrules are permanently attached to the tube by either welding or swaging.

For complete information on swaging, see Adel Wiggins Installation Manual WIM-III.

Downloadable PDF