

Wiggins Service Systems Components - PRESSURIZED RECEIVERS

ZNC4 Welded Receiver (with cap)

Flush Mount, Welded

ZNC2A External Mount Receiver (with cap)

External Mount

Note: ZC-20BP cap is used on ZNC3 and ZNC4. Caution:
The ZNC4 is shipped with the ZN2A nipple installed only finger tight.
Before welding the ZNC4 Receiver Assembly to the tank, remove the ZN2A
nipple from the threaded flange to prevent transferred heat from
damaging rubber seals in the ZN2A.

ZNC3 Bolted Receiver - Standard (with cap)

Flush Mount, Bolted - Standard

ZC-20P Cap

Note: Same as the ZC-20EP except lanyard cable has eyelet which is bolted to frame; used on ZN2A receiver.

Dry Break Connection and

[Automatic Shut Off](#)

[Ways to Mount Receivers](#)

[Specialty Tube Receivers](#)

[Notice to Buyers and Users](#)