Wiggins Service Systems Components - PRESSURIZED RECEIVERS

ZNC4 Welded Receiver (with cap)	
Flush Mount, Welded	
ZNC2A External Mount Receiver (with cap)	
External Mount	
Note: ZC-20BP cap is used on ZNC3 and ZNC4. Caution: The ZNC4 is shipped with the ZN2A nipple installed only finger tight. Before welding the ZNC4 Receiver Assembly to the tank, remove the ZN2A nipple from the threaded flange to prevent transferred heat from damaging rubber seals in the ZN2A.	
ZNC3 Bolted Receiver - Standard (with cap)	
Flush Mount, Bolted - Standard	
ZC-20P Cap	
Note: Same as the ZC-20EP except lanyard cable has eyelet which is bolted to frame; used of	on ZN2A receiver.
Dry Break Connection and	
ttp://fluidcontrol.net Powered by Joomla!	Generated: 23 October, 2018, 18:21

Automatic Shut Off

Ways to Mount Receivers

Specialty Tube Receivers

Notice to Buyers and Users

http://fluidcontrol.net Powered by Joomla! Generated: 23 October, 2018, 18:21